Hall Current Sensor EHN Series-T01

The EHN1000~3000A series are For the electronic measurement of currents:DC,AC,pulsed, with a galvanic isolation between the primary(high power) circuit and the secondary(electronic) circuit.



RoHS COMPLIANT

Electrical Specifications

Type		EHN 102-T01	EHN 202-T01	EHN 302-T01
Primary nominal DC. current	Ipn (A)	1000	2000	3000
Primary current measuring range	Ip (A)	DC≤1200 AC≤1000	DC≤2400 AC≤1800	DC≤3600 AC≤2600
Accuracy TA = 25 °C (excluding offset)	X	±0.5 % of I_{PN}		
Linearity (excluding offset)	L	±0.2% % of I_{PN}		
Overload capability（Imax）	Ip	18000A (The 18000A does not guarantee the accuracy)		
Output current	Iout	± 0.02 A		
Offset current @ TA = 25 °C	Io	< ± 0.1mA		
Hysteresis offset current @ IP = 0, after an excursion of 1 × IPN	Ioh	< ± 0.1 mA		
Power Consumption	Ic	0.15 A		
Supply voltage	Vcc	12V		
Temperature coefficient of Iout (% of reading)		< ±0.1 %/K		
Isolation voltage	Vd	4.4 KV RMS/50Hz/min,		
Impulse withstand voltage 1.2/50 μs	Uw	8.3 kV		
Isolation resistance	RIs	DC500V / 1000MΩ min		
Step response time to 90 % of IPN	Tr	< 5 μs		
Frequency bandwidth (0 ... −3 dB)	f	DC ... 25 kHz		
Operating temperature	To	-35 ~ +80°C		
Storage temperature	Ts	-40C ~ +85°C		

Mechanical Specifications

Output Type	Current(2EDG 5.08-4P)
Approx. Weight	860g

Tel: +86-0769-83608582 Fax: +86-0769-83608337 E-mail: sales@echun-elc.com www.echun-elc.com

Dimensions (unit: mm):









DC Current Sensor with Split Core 2KA-20mA

Connection:



Tel: +86-0769-83608582 Fax: +86-0769-83608337 E-mail: sales@echun-elc.com www.echun-elc.com

Notes:

1. Adjust the offset potentiometer to power it on for 3 minutes.
2. Two potentiometers can be adjusted, only if necessary, by turning slowly to the required accuracy with a small screwdriver.
3. Connect the terminals of power source, output respectively and correctly, never make wrong connection.
4. The best accuracy can be achieved when the window is fully filled with bus-bar (current carrying conductor).
5. The in-phase output can be obtained when the direction of current of current carrying conductor is the same as the direction of arrow marked on the transducer case.
6. The BUSBAR must be installed in the center of the window!
7. The OFFSET Used to adjust the zero point (Ip = 0), usually the output value < 0.03mA。
8. The GAIN Adjust the output current value (accuracy adjustment).

Tel: +86-0769-83608582 Fax: +86-0769-83608337 E-mail: sales@echun-elc.com www.echun-elc.com